

Systeme AXXIOS

Instructions de montage



Rims



1. Clean the adhesion points and the chip with a brake cleaner or degreaser.
2. Glue RACE-GRIP 120° in a staggered pattern with 3M double-sided tape
3. Briefly press the converter onto the rim with 3 fingers (10 seconds)
4. Cover with standard adhesive tape (without aluminium)

Puce

Red C

Nombre

3 par jante